



## Lo-AT Air Temperature Sensor

### Part #'s 52-1201 thru 52-1208, 52-1243

5V maximum input voltage

32 cells are calculated, for 16 or 8 cell input, use every other, or fourth cell as necessary

F°	$\Omega$
-10	132092
1	90320
12	62863
23	44481
34	31963
45	23302
56	17218
67	12884
78	9756
89	7471
100	5781
111	4518
122	3564
133	2836
144	2276
155	1840
166	1500
177	1231
188	1017
199	845
210	707
221	595
232	503
243	428
254	366
265	314
276	271
287	235
298	204
309	178
320	157
335	132